QUATROS®

Tool strength. Human power.

USER MANUAL

Set of 21 pcs. for fuel and air conditioning system connectors QS13123



26/07

PRODUCT DESCRIPTION

Application:
Universal kit designed for disconnecting fuel and air conditioning system connectors.

Kit contents:
- 4 pcs. adapters for "spring-lock" connectors in sizes (colors): red 3/8"; blue 1/2"; Black: 5/8"; White: 3/4"
- 6 pcs. adapters marked with different colors in the following sizes: 5/16", 3/8", 1/2", 5/8", 3/4", 7/8"
- 1 pc. Fuel System Connector Release Device
- 1 pc. FORD oil cooling hose connector jig
- 1 pc. fuel connector jig FORD, OPEL
- 7 pcs. Fuel Connector and Air Conditioning Adapters

USER MANUAL

NOTE: Before starting work, it is imperative that the system (air conditioning or fuel) is not pressurized. Disconnecting the lines under pressure risks serious injury or spraying hazardous substances.

1. Select an adapter that is the size of the cable you want to disconnect from the kit.
2. Open the adapter of your choice, place it directly on the air conditioning or fuel system tube, right next to the spring lock connector (or directly on the connector if you select "spring-lock connector adapter"), then close the adapter.
   NOTE: Make sure that the adapter sleeve is facing the connector that will be disengaged. Otherwise, it will not be possible to disconnect the wires.
3. Slide the adapter into the connector with a firm movement. Pushing the adapter sleeve into the inside of the fitting will widen the internal locking spring.
4. With the adapter pressed into the connector, pull the other end of the cord with your other hand to pull the connection apart.
   IMPORTANT: Due to the O-rings inside the cable to seal the connection, it may be necessary to disconnect the cables with a lot of force. Once disconnected, remove the tool from the cord.

WARRANTY CONDITIONS

1. TECHSAM warrants the proper operation of the product for a period of 12 months from the date of purchase.
2. The warranty includes free removal of defects and factory defects revealed during the warranty period.
3. The warranty does not cover mechanical damage or damage caused by improper use of the product.
4. The warranty expires if repairs or alterations are found by unauthorized persons.
5. The condition for considering the warranty is the presentation of the warranty card together with the complained product at the service point or at the point of sale.
6. The warranty is valid only with the seller's stamp and the date of sale.
7. Warranty and post-warranty service is provided by the importer.

P.W. TECHSAM WOCH Sp. J.
al. Warszawska 131
20-824 Lublin
tel. +48 81 444 63 73
E-mail: techsam@quatros.pl

Date of sale .....

Seller's signature and seal .....